



Ematic Model FTABMP2 Power Button Replacement

This guide will show you how to replace the power button of the Ematic Model FTABMP2.

Written By: Timothy






TOOLS:



- [iFixit Opening Tools](#) (1)
-

Step 1 — Power Button




- Use a spudger to pry open the case of your device to reveal the inside.

Step 2



- Disconnect the LCD cable from the motherboard by pressing together the two sides of the clamp to separate the device into two.

Step 3



- The plastic power button is not held in by anything and should just fall right out of your device. You can now take your new plastic power button and fit it into your device. Press the button and make sure you feel it clicking correctly.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 08:43:09 AM.